



## PARTS

ITEM No.	CODE No.	DESCRIPTION	USED No.	REMARKS
1	318228	SPECIAL SCREW (LEFT HAND) M5X27	1	
2	323250	DRILL CHUCK 10TLRK-N (W/O CHUCK WRENCH)	1	
3	324719	GEAR BOX ASS'Y	1	INCLUD.4-24
4	324114	CLUTCH DIAL	1	
5	324108	CLICK SPRING	1	
6	324109	NUT	1	
7	324110	SPRING	1	
8	324347	WASHER (D)	1	
9A	324720	FRONT CASE	1	
10	306936	STEEL BALL D5	6	
11	324111	RING GEAR	1	
12	324348	PLANET GEAR (C) SET (3 PCS.)	3	
13	324349	WASHER (A)	1	
14A	324501	REAR CASE	1	SINCE 7.2005 FOR RUS,NOR,FIN,SWE,DEN,
* 14A	324501			NZL,AUS SINCE 8.2005 FOR GBR,AUT,FRA,FRG
* 14A	324501			HOL,ITA,USA,KOR,CHN,TUR
15	324357	SCREW SET D3X12 (4 PCS.)	4	
16	324115	SHIFT ARM	1	
17	324351	SLIDE RING GEAR	1	
18	324112	PINION (C)	1	
19	324352	PLANET GEAR (B) SET (3 PCS.)	3	
20	324113	PINION (B)	1	
21	324354	PLANET GEAR (A) SET (3 PCS.)	3	
22	324353	FIRST RING GEAR	1	
23	324355	WASHER (B)	1	
24	324356	MOTOR SPACER	1	
25	318244	MOTOR	1	
26	313687	TAPPING SCREW (W/FLANGE) D3X16 (BLACK)	8	
27		NAME PLATE	1	
28	949203	MACHINE SCREW M3X8 (10 PCS.)	2	
29	949451	SPRING WASHER M3 (10 PCS.)	2	
30	324363	HOUSING (A),(B) SET	1	FOR USA,CAN (EXCEPT FOR USA,CAN TILL 12.2007) FOR RUS #J6837001-J6852000
30A	329179	HOUSING (A),(B) SET	1	(EXCEPT FOR USA,CAN SINCE 01.2008) (EXCEPT FOR RUS #J6837001-J6852000)
31	324121	INTERNAL WIRE (B) 90L (BLACK)	1	
32	324120	INTERNAL WIRE (B) 140L (RED)	1	
33	324119	DC-SPEED CONTROL SWITCH	1	FOR USA,CAN (EXCEPT FOR USA,CAN TILL 12.2007) FOR RUS #J6837001-J6852000
33A	329176	DC-SPEED CONTROL SWITCH	1	(EXCEPT FOR USA,CAN SINCE 01.2008) (EXCEPT FOR RUS #J6837001-J6852000)
34	324117	PUSHING BUTTON	1	FOR USA,CAN (EXCEPT FOR USA,CAN TILL 12.2007) FOR RUS #J6837001-J6852000
34A	329181	PUSHING BUTTON	1	(EXCEPT FOR USA,CAN SINCE 01.2008) (EXCEPT FOR RUS #J6837001-J6852000)
35	323229	FERRITE CORE	1	FOR EUROPE
36	324116	SHIFT KNOB	1	
37		HITACHI LABEL	1	
38		LABEL (CHINA)	2	
				FOR TPE
39	320287	HOOK ASS'Y	1	INCLUD.40
40	320288	V-LOCK NUT M5	1	
41	306952	STRAP (BLACK)	1	
42	315141	TERMINAL SUPPORT (A)	1	FOR USA,CAN (EXCEPT FOR USA,CAN TILL 12.2007) FOR RUS #J6837001-J6852000
42A	329174	BATTERY TERMINAL ASS'Y	1	(EXCEPT FOR USA,CAN SINCE 01.2008) (EXCEPT FOR RUS #J6837001-J6852000)

**PARTS**

ITEM No.	CODE No.	DESCRIPTION	USED No.	REMARKS
43	319926	HOOK SPRING	1	
44	319927	SPECIAL SCREW M5	1	
* 45	320387	BATTERY EB 1220BL (EUROPE)	2	
* 45A	322629	BATTERY EB 1214S (EUROPE,AUS,NZL)	2	
* 45A	324360	BATTERY EB 1214S (USA,CAN/CLAMSHELL)	2	FOR USA,CAN MEX
* 45A	324361	BATTERY EB 1214S (TPE)	2	FOR TPE
* 45A	324362	BATTERY EB 1214S (ASIA,ETC.)	2	FOR KOR
46	325245	FRONT CASE SET	1	INCLUD.9A,14A TILL 6.2005 FOR RUS,NOR,
* 46	325245			FIN,SWE,DEN,NZL,AUS TILL 7.2005 FOR GBR,
* 46	325245			AUT,FRA,FRG,HOL,ITA,USA,KOR,CHN,TUR
STANDARD ACCESSORIES				
				EXCEPT FOR GBR

**STANDARD ACCESSORIES**

ITEM No.	CODE No.	DESCRIPTION	USED No.	REMARKS
501		CHARGER (MODEL UC 18YG)	1	
502	983006	+ DRIVER BIT NO.2 65L	1	
503		BIT SET	1	
504		TORCHLIGHT (MODEL UB 12D)	1	
505	324083	CASE (BLACK)	1	
* 505	330062	CASE	1	FOR WEST EUROPE